

USER GUIDE – SPRINT KYOCERA TORQUE HOME SCREEN

Intro

Purpose:

This user guide explains how to customize your home screen on a Sprint Kyocera Torque smart phone.

Requirement:

Android Sprint Kyocera Torque smart phone

Note: Use your fingertip or a stylus. Don't use your fingernail.



1

Getting started

To see your apps, at the bottom of the screen, touch the circle.

Note: The smart phone opens to the Home screen.



2

Adding apps to the Home screen

To move an app to the home screen, touch and hold down on an app icon.

